

ICE Guard®

Sump Pump Discharge Line System

The IceGuard® System allows water to escape from a sump pump discharge line if the pipe freezes or becomes blocked for any reason. Even if the pipe outlet is buried under a foot of ice and snow, the water can escape, allowing your sump pump to keep your basement dry. When the discharge pipe thaws, the water will automatically run along its normal


route, and no water will escape from the IceGuard®. There are no valves to turn, hoses to attach, or anything for the homeowner to do at all – it's totally automatic!



Sump discharge lines like this one can freeze.



Pipe terminations like this one will be covered with snow and ice in the winter. This is not a problem if you have the IceGuard® System!



The patented design of the IceGuard® System automatically allows water to escape through its perforations. This unique feature provides an exit when pipe terminations are blocked, usually by ice or snow.



**Common Sense
at Work®**

This photo shows a home that was saved by the IceGuard® System. When the discharge line was covered by snow & ice and froze, the IceGuard® allowed the water to escape during repeated pump cycles. IceGuard® saved this basement even in these extreme conditions!

